

## WESTERN FLASHBACK ARRESTORS—OXY/FUEL GAS

Welders rely on Western's advanced Flashback Arrestors to help prevent serious incidents caused by reverse gas flows or flashbacks. Western's Flashback Arrestors are designed to stop flashbacks by preventing ignition of mixed gases and to protect equipment such as hoses, regulators and cylinders.

### FEATURES AND SPECIFICATIONS

- Color-coded for gas service to provide added safety—oxygen (green), fuel gas (red)
- Internal check valves designed to prevent reverse flow and accidental mixing of oxygen and fuel gases
- Maximum operating pressures are 15 PSIG for acetylene, 22 PSIG for other fuel gases, and 125 PSIG for oxygen
- Rated capacity of 40 SCFH with a 5 PSIG pressure drop
- Torch and Regulator models provide downstream and upstream protection
- 10" maximum cutting capacity
- Reusable; manual resetting not required
- UL listed and 100% tested
- Complete installation, testing and operating instructions included
- Safe-Mate models feature quick connect design for quick and easy installation and disconnection
- 316 stainless steel flame trap

PART NO.	DESCRIPTION	COMPONENTS
<b>FLASHBACK ARRESTOR SETS</b>		
FA-10*	Flashback Arrestor Set, Torch Style	FA-100P, FA-200P
FA-30*	Flashback Arrestor Set, Regulator Adaptor Style	FA-130P, FA-230P
<b>FLASHBACK ARRESTOR COMPONENTS</b>		
FA-100P	Flashback Arrestor, Oxygen, Torch Style, B Size	
FA-200P	Flashback Arrestor, Fuel Gas, Torch Style, B Size	
FA-130P	Flashback Arrestor, Oxygen, Regulator Adaptor Style, B Size	
FA-230P	Flashback Arrestor, Fuel Gas, Regulator Adaptor Style, B Size	

**FLASHBACK ARRESTORS**  
B-SIZE, 9/16" - 18

FA-230P      FA-130P

FA-30 SET

\*Sold in retail clamshell packaging

PART NO.	DESCRIPTION
<b>FLASHBACK ARRESTOR COMPONENTS</b>	
<p>FA-71      FA-70</p>	FR50-OX      Flashback Arrestor, Oxygen, Regulator Style, B Size
	FR50-F      Flashback Arrestor, Fuel Gas, Regulator Style, B Size
	FA-60      Flashback Arrestor, Oxygen, Torch Style, C Size
	FA-61      Flashback Arrestor, Fuel Gas, Torch Style, C Size
	FA-70      Flashback Arrestor, Oxygen, Regulator Style, Resettable, B Size
	FA-71      Flashback Arrestor, Fuel Gas, Regulator Style, Resettable, B Size
	FA-80      Flashback Arrestor, Oxygen, Torch Style, A Size
	FA-81      Flashback Arrestor, Fuel Gas, Torch Style, A Size
	FA-90      Flashback Arrestor, Oxygen, Regulator Style, A Size
	FA-91      Flashback Arrestor, Fuel Gas, Regulator Style, A Size

### SAFEMATES—QUICK CONNECT SETS WITH BUILT-IN FLASHBACK ARRESTORS

PART NO.	DESCRIPTION
QDF10	Torch-to-Hose Set w/Check Valves (Oxy/Fuel Gas)
QDF30	Regulator-to-Hose (Oxy/Fuel Gas)