

# INDUSTRIAL FLOWMETERS

## RP SERIES PRESET FLOW REGULATORS (FROG)

The RP Series Preset Flow Regulators models are compact flow regulated orifice gauges (F.R.O.G.) designed to supply a preset flow of inert shielding gas for GMAW or GTAW welding applications. A built in "cylinder content indicator" warns the user when the cylinder of shielding gas is near depletion. The single stage piston design provides value and performance for the novice welder.

- Dependable brass piston with PCTFE Seat
- Machine brass body resists corrosion
- Internal safety relief protects against over pressurization
- Inlet filter extends service life
- Hose barb outlet for 3/16" and 1/4" ID hose
- One year warranty
- Made in the USA



**RP30580**

MODEL	CGA INLET GAS SERVICE	FLOW CAPACITY (SCFH)	INLET PRESSURE (PSIG)	OUTLET HOSE BARB
RP22320	320 Carbon Dioxide	22	0-3000	3/16" & 1/4" ID hose
RP30580	580 Argon	30	0-3000	3/16" & 1/4" ID hose

## REB SERIES COMPACT FLOW GAUGE REGULATORS

The REB Series Flow Gauge Regulators offer a compact, lightweight alternative to conventional flowmeters. These single stage regulators include a delivery gauge that is dual calibrated in standard cubic feet per hour (SCFH) for both Argon and Carbon Dioxide. The flow gauge works in conjunction with an outlet metering orifice to deliver the precise gas flow necessary for GMAW or GTAW welding applications.

- Machine brass body resists corrosion
- Neoprene diaphragm maintains consistent flow rates
- PCTFE seat assembly
- Inlet filter extends service life
- 2" easy to read gauges
- Dual scale flow gauge calibrated for Argon or Carbon Dioxide service
- Three year warranty
- Made in the USA



**REB-3-FG**

MODEL	CGA INLET GAS SERVICE	FLOW CAPACITY (SCFH)	INLET PRESSURE (PSIG)	OUTLET (BOTH PROVIDED)
REB-3-FG	580 Argon	0-35	0-3000	9/16"-18 RHM 5/8"-18 RHF
REB-3-FGD* Display Package	580 Argon	0-35	0-3000	9/16"-18 RHM 5/8"-18 RHF
REB-4-FG	320 Carbon Dioxide	0-35	0-3000	9/16"-18 RHM 5/8"-18 RHF
REB-4-FGD* Display Package	320 Carbon Dioxide	0-35	0-3000	9/16"-18 RHM 5/8"-18 RHF

\*Includes 6' neoprene hose with fittings

Made In The U.S.A.