

INDUSTRIAL FLOWMETERS

REF SERIES COMPACT FLOWMETER REGULATORS

The REF Series Flowmeter Regulator models combine a single stage piston regulator with a dual calibrated flow tube to provide a compact, lightweight, economical solution for all GMAW and GTAW welding applications. The REF Series, with its durable brass piston, is designed to meet all the needs of the professional welder.

- Dependable brass piston with PCTFE Seat
- Machine brass body resists corrosion
- Dual Inlet filter extends service life
- Shatter resistant, dual calibrated flow tube, calibrated for Argon and CO₂
- Needle valve for precise adjustments
- Includes 6 ft. hose with fittings, in retail packaging
- Three year warranty
- Made in the USA



MODEL	CGA INLET GAS SERVICE	FLOW CAPACITY (SCFH)	INLET PRESSURE (PSIG)	OUTLET (BOTH PROVIDED)
REF-3-PD* Display Package	580 Argon	0-70	0-3000	9/16"-18 RHM 5/8"-18 RHF
REF-3-PGD* Display Package	580 Argon with gauge	0-70	0-3000	9/16"-18 RHM 5/8"-18 RHF
REF-4-PD* Display Package	320 Carbon Dioxide	0-70	0-3000	9/16"-18 RHM 5/8"-18 RHF
REF-4-PGD* Display Package	320 Carbon Dioxide with gauge	0-70	0-3000	9/16"-18 RHM 5/8"-18 RHF

*Includes 6' neoprene hose with fittings